

Charging Procedure

To charge the TSI Flow Meter battery:

1. Connect the charger to the TSI Flow Meter.
2. Connect the charger to the mains supply.
3. Switch on the mains supply.

Confirming Battery Charging

To confirm that battery charging has started, the charger indicator should show **orange** immediately after connection.

Orange LED – Battery Charging

Important

If the charger indicator does not show orange immediately after connection, disconnect the charger and repeat the charging procedure above.

If the charger indicator still does not show orange, please contact TSI Technical Support.

Need Assistance?

If you have any questions regarding battery charging or the operation of your TSI Flow Meter, please contact TSI Technical Support.